

**To Calculate the correct bolt length:**

**Measure the distance between the top of the ring and the top of the clevis pin to the nearest 1/8"**

**The minimum clearance is 1 3/4 inch**

<b>Measurement</b>	<b>Minimum Bolt length</b>	<b>Maximum Bolt Length</b>
<b>&lt; 1 1/2</b>		<b>Call for non-standard installation kit.</b>
<b>1 1/2</b>	<b>1 3/4</b>	<b>2 + extra washer</b>
<b>1 5/8</b>	<b>2</b>	
<b>1 3/4</b>	<b>2</b>	<b>2 1/4 + extra washer</b>
<b>1 7/8</b>	<b>2 1/4</b>	
<b>2</b>	<b>2 1/4</b>	<b>2 1/2 + extra washer</b>
<b>2 1/8</b>	<b>2 1/2</b>	
<b>2 3/8</b>	<b>2 1/2</b>	<b>2 3/4 + extra washer</b>
<b>2 1/2</b>	<b>2 3/4</b>	
<b>2 5/8</b>	<b>2 3/4</b>	<b>3 + extra washer</b>
<b>2 3/4</b>	<b>3</b>	
<b>2 7/8</b>	<b>3</b>	<b>3.25 + extra washer</b>
<b>3</b>	<b>3 1/4</b>	
<b>3 1/8</b>	<b>3 1/4</b>	<b>3.5 + extra washer</b>